

# Lab 2


SUBJECT TEACHER DATE

IoT Hands-On Lab Bob Familiar November 19, 2015

### **OVERVIEW**

This lab involves provisioning IoT Hub and creating a Stream Analytics Jobs that reads incoming device telemetry and output to DocumentDb. These steps are done manually so that you can get firsthand experience with the configuration settings of these services. As demonstrated in Lab 1, all of these steps can be automated through PowerShell.

# STEP 1 • Navigate to <a href="http://portal.azure.com">http://portal.azure.com</a>. • Select '+ New', 'Internet of Things', 'Azure IoT Hub'. • Create a unique name for your IoT Hub using your user tag such as user023IoTHub • Select your resource group • Select East US for the location • Click 'Create' • Wait for your IoT Hub to be provisioned before moving to Step 2



# STEP 2 • Once the IoT Hub is provisioned, you will be able to gather the connection information for your end point. • Click 'Shared Access Policies', then 'IoTHubOwner' to reveal the private key and the connection string. Open up Notepad and copy the private key and connection string into a text file for later reference. STEP 3 • Navigate to your DocumentDb instance and add a database called 'Biometrics' • Select that database and add a collection called 'Alarms' STEP 4 • Go back to the top level of the portal blade navigation and click '+ New', 'Internet of Things', 'Stream Analytics Job'. • Create a unique name for your job using your user tag, for example: user023SAJob1 Select the subscription • Click 'Existing Resource Group' and select your resource group Select East US for the location Click 'Create' • Wait for the Stream Analytics Job to complete provisioning before moving on to Step 4 STEP 5 • Once the Stream Analytics Job has been provisioned, you can define the Input, Output and Query. Click 'input', 'add', and fill out the form. • Enter 'input' for alias • Enter the name of your IoT Hub • Set the shared access policy name to 'iothubowner' • Paste the IoT Hub private key into the shared access policy key field

• Click create


• Check to make sure the test connection

passes before continuing

## STEP 6 Click 'output', 'add' and fill out the formEnter 'output' as the alias • Select SQL Database as the Sink • Enter the server name; it has the format userNNNsqlserveruserNNN • Enter the database name; BiometricsDb • Enter the username: BioMaxUser001 • Enter the password: BioMaxPass001 • Enter the table name: biometrics user003SAJob1 + Add U iii Created user003sqlserveruser003 Essentials ^ 21 88 O HOL\_RG\_user003 HOLBiometricsDb Region East US Tuesday, November 3, 2015 9:06:35 PM Subscription name bobfamiliar\_test Subscription id 77d19f95-8966-4b89-87a1-beb03450dd60 Job Topology \* Table biometrics Query 1 ⊕ 1 → <> output Monitoring InputEvents, OutputEvents and one more metric past hour STEP 7 • Click 'query' and enter the following SQL statement into the editor: WITH Device as (SELECT \* from input) SELECT Device.deviceid, Device.participantid, Device.location.longitude, Device.location.latitude, Device.reading, DeviceSensors.ArrayValue.type, DeviceSensors.ArrayValue.value INTO output FROM

CROSS APPLY GetElements(Device.sensors) AS DeviceSensors

• Click 'Save'



((DeviceSensors.ArrayValue.type = 1) AND (DeviceSensors.ArrayValue.value > 180))

• On the Essentials Blade, click `Start'